

**MOUNTING the PUSHrack L-TRACK SET on the Ford Transit, H3 from model year 2014, rails 70cm each**

**Requirements**

- The lower rail is at least 45 cm from the lower edge of the vehicle (bumper).
- Distance between the rails is between 100 and 130 cm
- Rails must be screwed and glued
- The supplied reinforcement plates must be installed on the inside
- The assembly videos must be watched in full in advance. Please scan the QR code →
- Attention: The sheet metal on the inside of the door must be cut out for installation

