

Stand: 29.4.2025

MOUNTING of the PUSHrack L-Track Set on Mercedes Sprinter, H2 & H3 since BJ2006, rail top 60 cm / rail below 70cm



Requirements

- The lower rail is at least 45 cm from the lower edge of the vehicle (bumper).
- Distance between the rails is between 100 and 130 cm
- Rails must be screwed and glued
- The supplied reinforcement plates must be installed on the inside
- The assembly videos must be watched in full in advance. Please scan the QR code →



FWD:
A: 485 mm
B: 1740 mm

4WD & RWD:
A: 405 mm
B: 1660 mm

Questions? Please contact us: support@pushcomponents.com