


# Anleitung PUSHrack Anti-Diebstahlset



## User manual PUSHrack anti-theft set

Die Anti-Diebstahl Mutter ist asymmetrisch. Die Nuss passt nur in einer Position.

The anti-theft nut is asymmetrical. The nut only fits in one position.



Copyright by Adventure Xperience

PRNT0050-0301

