



USER MANUAL
HOOKABIKE



Content

Introduction	3
Intended Purpose	3
How To	4
Safety Instructions	6
Specifications	7
Disposal	7
Problems and Solutions	7

Introduction

We are very glad that you have chosen a HOOKABIKE. Before using for the first time, read the instructions carefully and observe the safety instructions.

Have fun carrying and on the trail afterwards!

Manufacturer:

PUSH components Schindelka & Dann GbR
Jahnweg 19
83714 Miesbach
Germany


Email: info@pushcomponents.com

Intended Purpose

The HOOKABIKE was developed exclusively for carrying bicycles on a backpack. Please note our specifications and safety instructions.


How To

Step 1:




Mount the base plate as close as possible with the velcro straps on your backpack straps.

Attention: Make sure that the velcro straps are properly closed.



TIP: For backpacks with additional straps, the base plate is positioned underneath.


Step 2:



Attach the frame strap to the down tube approximately 15 cm (6 in) in front of the bottom bracket. The silver pin must point horizontally to the left.


TIP: Vary the position of the belt for the perfect balance of your bike on your back.

Attention: Make sure that the frame strap is properly closed

Step 3:

Grab your bike from the left side by the fork and crank.

TIP: Turn the left pedal down before you grab the crank. If your bike is too heavy this way, you can also take the bike on the lower end of the saddle tube.

Step 4:

Lift your bike over your head.

TIP: When lifting over the head make sure that the silver pin is centered above you.

Step 5:

Put your bike on your shoulders. Now if you feel the silver pin on your neck, you are right in the middle. Now let your bike slide down into the guide of the plate.

TIP: If you are not sure if you have already hit, keep holding your bike with your right hand on the crank and check with your left hand if the pin is snapped into the plate.

Step 6:

For the downhill stow the base plate in the backpack.

Safety Instructions

- » Before each use, check that the base plate and the frame strap are properly mounted.
- » After putting the bike on your shoulders, check if the bike is locked securely. Only then can you let the bike go.
- » Only carry the bike in an upright posture.
- » Keep the velcro straps clean for maximum performance. If necessary, clean them with water and let them dry before the next use.
- » Note that when wet, the performance of the velcro straps is reduced. If necessary, dry the velcro straps.
- » When carrying your bike consider the larger space requirement and changed center of gravity.
- » The bike can be pulled out of the holder by trees, shrubs, rocks or the like. Hold it with at least one hand in such situations.
- » Load the HOOKABIKE only according to the specifications.
- » Check the allowable weight of your backpack. If the load is too high, the backpack may be damaged.
- » HOOKABIKE is a bike carrying aid and no fixation. For your own protection, your bike can come off.

Specifications

- » Temperature range usage: -5 to +40 °C / +23 to +104 °F
- » Storage: at room temperature
- » Maximum load: 25 kg / 55.1 lbs

Attention: Note the allowable weight for your backpack and extra weight with attached equipment, water bottles, and the like.

Disposal

Before you dispose your HOOKABIKE because something has broken down, contact us, maybe we can help you. In the event that help is no longer possible please help keeping the environment clean and dispose the HOOKABIKE according to local regulations.

Problems and Solutions

If you have problems with your HOOKABIKE, please contact us.

PUSH components Schindelka & Dann GbR
Jahnweg 19
83714 Miesbach
Germany

Email: info@pushcomponents.com



The PUSH components team wishes you a lot of fun while carrying and on the trail afterwards!